



**B.M. MACCHINE UTENSILI s.r.l.**

Via Edmondo De Amicis, 146 - 10093 Collegno (TO) - ITALY

Tel: (0039) 011-403.11.24 / 011-403.15.79 - Fax: (0039) 011 403.13.28

www.bmtorino.it - bm@bmtorino.it

IT 07417070013

**INDRAMAT**

Code 6217



**VARIOUS**

**VARIA**

Brushless Motor	Type	Tipo	Brushless Motor
<b>MAC63D-0-FS-4-C/95-A-1/WI572L/S06</b> servomotor <b>MAC090B-0-JD-4-C/110-A-1/WI517LV/S005</b> servomotor <b>MAC090B-0-JD-4-C/110-A-0/WI534LX/S001</b> servomotor <b>MAC093A-0-PS-4-C/110-B-0/WI520LV</b> servomotor <b>MAC093B-0-JS-4-C/110-A-0/WI594LV</b> servomotor	Accessories	Accessorios	<b>MAC63D-0-FS-4-C/95-A-1/WI572L/S06</b> servomotor <b>MAC090B-0-JD-4-C/110-A-1/WI517LV/S005</b> servomotor <b>MAC090B-0-JD-4-C/110-A-0/WI534LX/S001</b> servomotor <b>MAC093A-0-PS-4-C/110-B-0/WI520LV</b> servomotor <b>MAC093B-0-JS-4-C/110-A-0/WI594LV</b> servomotor
<b>MAC112A-0-LD-2-C/130-A-0/S09</b> servomotor <b>MAC112B-0-LD-2-C/130-A-1//S005</b> servomotor <b>MAC112B-0-LD-2-C/130-A-0//S005</b> servomotor <b>MAC112D-0-ED-1-B/130-B-0/J625/S05</b> servomotor	Notes	Notas	<b>MAC112A-0-LD-2-C/130-A-0/S09</b> servomotor <b>MAC112B-0-LD-2-C/130-A-1//S005</b> servomotor <b>MAC112B-0-LD-2-C/130-A-0//S005</b> servomotor <b>MAC112D-0-ED-1-B/130-B-0/J625/S05</b> servomotor

The characteristics, data, measurements and photos provided here are not binding  
Características, datos, medidas y fotos no suponen compromiso ninguno