



**B.M. MACCHINE UTENSILI s.r.l.**

Via Edmondo De Amicis, 146 - 10093 Collegno (TO) - ITALY

Tel: (0039) 011-403.11.24 / 011-403.15.79 - Fax: (0039) 011 403.13.28

www.bmtorino.it - bm@bmtorino.it

IT 07417070013

**OMLAT**  
Code 5617



**CHUCK - DIVIDING HEAD**

**HUSILLO - DIVISOR**

| <b>Electrospindle</b>                              | Type        | Tipo  | <b>Electrohusillo</b>                                    |
|--|-------------|-------|--|
| Serial number                                      | <b>1132</b> |       | Matrícula  |
| <b>Electrospindles OMLAT - Movement adjustment</b> | Notes       | Notas | <b>Electrohusillos OMLAT - Regulación desplazamiento</b> |

The characteristics, data, measurements and photos provided here are not binding  
Características, datos, medidas y fotos no suponen compromiso ninguno